
COAL AND ASH HANDLING PLANT



coal is fed into a rotary coal filler D, which automatically fills each conveyor bucket with a full complement of coal without spilling any over the sides of the bucket. The conveyor chain E passes under the rotary filler already